

		1	2	3	4	5		6	7	8																																																																																														
F						LTR	REV	ECN NUMBER	DESCRIPTION	DATE	REVISED	APPROVE																																																																																												
						1	XA		新版发行	2023-04-25	CYC	LZ																																																																																												
E																																																																																																								
D		<p>NOTES:</p> <ol style="list-style-type: none"> Electrical <ul style="list-style-type: none"> .Rated Current & Voltage : DC 12 V ; 3.0A Max. .Contact Resistance: 50 mohm maximum at Working Height(Quiescence) Mechanical <ul style="list-style-type: none"> .Full store: 0.70 mm .Working Store: 0.50 mm .Spring Force: 40gf±10gf at Working Height .Durability:10,000 cycles(minimum) Environmental <ul style="list-style-type: none"> .Operating Temperature: -25° C~+85° C .Humidity Range: 10%RH~90%RH .Salt Spray: 48 Hours Male and female docking magnetic force: 850gf MIN. When the current is greater than 1A then need to increase the time delay circuit(3 second) To avoid arcing issue, The adaptor start to power supply after connector mated fully. To ensure the best usage,please operate it based on the working height. RoHs&HF compliant product. 																																																																																																						
C		<p>技术要求:</p> <ol style="list-style-type: none"> 开路、短路、错位、瞬间开/短路必须100%测试 导通阻抗: 3Ω MAX 绝缘阻抗: 5MΩ MIN,DC 300V/0.01S 外观无刮伤、压伤、异物等不良 																																																																																																						
B		<p>WIRE LIST</p> <table border="1"> <thead> <tr> <th></th> <th>P1</th> <th>P2</th> </tr> </thead> <tbody> <tr> <td>OPEN</td> <td>红</td> <td>1 (Vcc)</td> </tr> <tr> <td>OPEN</td> <td>白</td> <td>2 (D-)</td> </tr> <tr> <td>OPEN</td> <td>绿</td> <td>3 (D+)</td> </tr> <tr> <td>OPEN</td> <td>黑</td> <td>4 (GND)</td> </tr> <tr> <td>OPEN</td> <td>黄</td> <td>5</td> </tr> <tr> <td>OPEN</td> <td>蓝</td> <td>6</td> </tr> </tbody> </table>											P1	P2	OPEN	红	1 (Vcc)	OPEN	白	2 (D-)	OPEN	绿	3 (D+)	OPEN	黑	4 (GND)	OPEN	黄	5	OPEN	蓝	6																																																																								
	P1	P2																																																																																																						
OPEN	红	1 (Vcc)																																																																																																						
OPEN	白	2 (D-)																																																																																																						
OPEN	绿	3 (D+)																																																																																																						
OPEN	黑	4 (GND)																																																																																																						
OPEN	黄	5																																																																																																						
OPEN	蓝	6																																																																																																						
A		<table border="1"> <thead> <tr> <th>5</th> <th>4</th> <th>3</th> <th>2</th> <th>1</th> <th>Q' TY</th> <th>UNIT</th> <th>DATE</th> <th>2023-04-25</th> <th>SCALE</th> <th>UNITS</th> <th>HSF</th> <th>东莞市双盟电子有限公司</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td>胶料</td> <td>TPE, 黑色, 85A, RoHS+REACH</td> <td>A/R</td> <td>G</td> <td></td> <td></td> <td></td> <td>NONE</td> <td>mm</td> <td>compliant</td> <td></td> </tr> <tr> <td></td> <td>11W02-00001-01</td> <td>胶料</td> <td>PE, 透明料, RoHS+REACH</td> <td>A/R</td> <td>G</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td>PCB</td> <td>6P POGO 公PCB板, 双层板, RoHS+REACH</td> <td>1</td> <td>PCS</td> <td>APPROVE</td> <td></td> <td></td> <td></td> <td>GENERAL TOLERANCE</td> <td></td> <td>TITLE. 6Pin 磁吸公 TO OPEN L=200mm BLACK</td> </tr> <tr> <td></td> <td></td> <td>POGO PIN</td> <td>6P POGO PIN +磁铁+黑色塑胶 (型号:PPM.06-888-0502) RoHS+REACH</td> <td>1</td> <td>PCS</td> <td>CHECK</td> <td></td> <td></td> <td></td> <td>.x ± 0.30</td> <td>.x° ±</td> <td>Product P/N. PCM.06-1594-0502</td> </tr> <tr> <td></td> <td></td> <td>线材</td> <td>NO-UL 22AWG (红黑65/0.08TC)*2C+30AWG (白绿蓝黄11/0.08TC)*4C BLACK TPE OD4.0mm</td> <td>A/R</td> <td>MM</td> <td>DRAW</td> <td></td> <td></td> <td></td> <td>.xx ± 0.20</td> <td>.x° ±</td> <td>Customer P/N.</td> </tr> <tr> <td>SIZE : A4</td> <td>NO.</td> <td>PART NO.</td> <td>ITEM</td> <td>DESCRIPTION</td> <td>Q' TY</td> <td>UNIT</td> <td>DATE</td> <td>2023-04-25</td> <td></td> <td>.xxx ± 0.10</td> <td></td> <td>DWG NO. 1594</td> <td>SHEET. 1/1</td> <td>REV XA</td> </tr> </tbody> </table>										5	4	3	2	1	Q' TY	UNIT	DATE	2023-04-25	SCALE	UNITS	HSF	东莞市双盟电子有限公司			胶料	TPE, 黑色, 85A, RoHS+REACH	A/R	G				NONE	mm	compliant			11W02-00001-01	胶料	PE, 透明料, RoHS+REACH	A/R	G										PCB	6P POGO 公PCB板, 双层板, RoHS+REACH	1	PCS	APPROVE				GENERAL TOLERANCE		TITLE. 6Pin 磁吸公 TO OPEN L=200mm BLACK			POGO PIN	6P POGO PIN +磁铁+黑色塑胶 (型号:PPM.06-888-0502) RoHS+REACH	1	PCS	CHECK				.x ± 0.30	.x° ±	Product P/N. PCM.06-1594-0502			线材	NO-UL 22AWG (红黑65/0.08TC)*2C+30AWG (白绿蓝黄11/0.08TC)*4C BLACK TPE OD4.0mm	A/R	MM	DRAW				.xx ± 0.20	.x° ±	Customer P/N.	SIZE : A4	NO.	PART NO.	ITEM	DESCRIPTION	Q' TY	UNIT	DATE	2023-04-25		.xxx ± 0.10		DWG NO. 1594	SHEET. 1/1	REV XA
5	4	3	2	1	Q' TY	UNIT	DATE	2023-04-25	SCALE	UNITS	HSF	东莞市双盟电子有限公司																																																																																												
		胶料	TPE, 黑色, 85A, RoHS+REACH	A/R	G				NONE	mm	compliant																																																																																													
	11W02-00001-01	胶料	PE, 透明料, RoHS+REACH	A/R	G																																																																																																			
		PCB	6P POGO 公PCB板, 双层板, RoHS+REACH	1	PCS	APPROVE				GENERAL TOLERANCE		TITLE. 6Pin 磁吸公 TO OPEN L=200mm BLACK																																																																																												
		POGO PIN	6P POGO PIN +磁铁+黑色塑胶 (型号:PPM.06-888-0502) RoHS+REACH	1	PCS	CHECK				.x ± 0.30	.x° ±	Product P/N. PCM.06-1594-0502																																																																																												
		线材	NO-UL 22AWG (红黑65/0.08TC)*2C+30AWG (白绿蓝黄11/0.08TC)*4C BLACK TPE OD4.0mm	A/R	MM	DRAW				.xx ± 0.20	.x° ±	Customer P/N.																																																																																												
SIZE : A4	NO.	PART NO.	ITEM	DESCRIPTION	Q' TY	UNIT	DATE	2023-04-25		.xxx ± 0.10		DWG NO. 1594	SHEET. 1/1	REV XA																																																																																										
<p>PRODUCT DRAWING</p>																																																																																																								

本公司所有產品為HSF產品，選材時不可使用《有害物質管理標準》內限用之物料。對客戶特殊制定之原材料，如成型樹脂、油墨、塗料、被覆電線等，應從客戶指定之供應商購買。